


QUICK START GUIDE



You're pages away from the perfect cup.

STEP 1: **MEET YOUR TOOLS**

FOLLOW THESE STEPS TO GET SET UP, MAKE YOUR FIRST DRINK, AND CARE FOR YOUR MACHINE.



ASSISTED TAMPER



FUNNEL Always install funnel before grinding. Dishwasher safe.



SINGLE BASKET DOUBLE BASKET LUXE BASKET Dishwasher safe.



PORTAFILTER

Double basket comes installed in the portafilter.



THOROUGHLY CLEAN AND DRY ALL ITEMS BEFORE PROCEEDING.

STEP 2: **TEST WATER HARDNESS**


2.

All water has minerals that can build up in the machine over time. These minerals are referred to as water hardness and can impact how often you need to descale your machine.


1.



Submerge test strip in water for 5-10 seconds.



You will see O-5 purple squares appear. This will indicate the water hardness level of your water (O purple squares=level O, 5 purple squares=level 5, etc).




Turn the centre dial to set your water hardness by matching your setting to how many purple squares you see (will range from 0–5 squares). Press centre dial to confirm your setting.*

*IF YOU NEED TO SET YOUR WATER HARDNESS LEVEL AGAIN, SEE OWNER'S GUIDE.



Remove test strip and wait 1 minute.


4.



Plug in machine and press power button.


STEP 3: WATER FILTER INSTALLATION

1.




Soak Water Filter for 5 minutes.

3.




Secure filter into filter housing.

5.




Install filter housing into reservoir.

2.




Rinse water filter and mesh for 60 seconds.

4.



Set date 2 months ahead.


6.



Return water reservoir to machine.

STEP 4: FILL WATER RESERVOIR & BEAN HOPPER

.




2.



Fill reservoir to max line with water, then place back on machine.

3.



Fill the bean hopper with whole beans.

STEP 5: FLUSH YOUR MACHINE

YOU MUST RUN A WATER FLUSH BEFORE FIRST USE. DO THIS ONLY ONCE.

1.




Align portafilter with orange dot on group head.

3.



Select CLASSIC.

5.




Place a 420ml or large cup under the portafilter.

7.



When finished, the machine will beep again, signifying the brew is complete. Discard the water, then rinse and dry the portafilter.

2.



Fasten portafilter to align with lock arrow.

4.



Press the Size Selection button to adjust drink size to **M+**.

6.



Press Start Brew. This will take about 2 minutes.

CALIBRATING YOUR MACHINE




YOU MUST DO THIS BEFORE BREWING YOUR FIRST ESPRESSO DRINK. DO THESE STEPS 2-3 TIMES TO CALIBRATE YOUR MACHINE.

STEP 1: PREP YOUR MACHINE



Double basket comes installed in the portafilter.

2.




Place funnel on portafilter. Push down until funnel locks into place.

3.



Insert portafilter in the grinding cradle. Make sure it is level and fits securely.



Turn the centre dial to select **ESPRESSO**

STEP 2: GRIND THE BEANS



Check to see if the current grind setting matches the recommended setting.

Note: The numbers displayed in the images are for reference only and may not match what is displayed on



If they don't match, adjust current grind size by spinning the grind dial on left side of machine until it matches the recommended setting.

3.



Press **START GRIND**. Do not touch portafilter until grinding is

STEP 3: **BREW ESPRESSO**



On a solid level surface with funnel still attached, press tamper all the way down until it meets funnel.




Remove funnel from portafilter.



Align portafilter with orange dot on group head.



Fasten portafilter to align with lock arrow.



Place a 355ml or large cup under the



Press START BREW. The machine will beep to signal the brew has started. The progress bar will illuminate, indicating the status of the brew. This will take about 30 seconds.

7.



When finished, the machine will beep again to signify the brew is complete. Remove cup then carefully remove portafilter from group head. Dispose of grounds by tapping the surface of the basket over a container or knock box*.

PLEASE USE CAUTION AS PORTAFILTER WILL BE HOT

*KNOCK BOX SOLD SEPARATELY AT NINJAKITCHEN.CO.UK/NINJA-PARTS-ACCESSORIES/

STEP 4: **REPEAT PROCESS**

- Now that your first brew is complete, discard the drink and repeat steps 1-3.
- Once your second brew is complete, Barista Assist Technology will have dialed in the recommended grind setting to get perfect extraction. The machine is now ready to make
- Please note that you will have to do this whenever you are switching the type of beans you are putting in the hopper.

FOR MORE INFORMATION, REFER TO UNDERSTANDING BARISTA ASSIST TECHNOLOGY.

ESPRESSO 101:

MAKING YOUR FIRST ESPRESSO DRINK

Once you've primed your machine, brew your first espresso drink



BEGINNER RECIPE ●○○

MAKES: 1 SERVING


INGREDIENTS

Fresh coffee beans Milk of choice



STEP 1: **PREP YOUR DRINK**

1.




Place funnel on portafilter. Push down until funnel locks into place.

2.



Insert portafilter into the grinding cradle. Make sure it is level and fits securely.

3.



Turn the centre dial to select **ESPRESSO**.

STEP 2: **GRIND THE BEANS**

1.



Check to see if the current grind setting matches the recommended setting.

Note: The numbers displayed in the images are for reference only and may not match what is displayed on your machine.

2.



If they don't match, adjust current grind size by spinning the grind dial on left side of machine until it matches the recommended setting.

3.



Press **START GRIND**. Do not touch portafilter until grinding is completed.


NOTE: Once a grind is complete, the machine will be set to the brew style and size that was selected for that grind. To change style and size, pour grounds out of portafilter, power the machine off and on, and restart from Step 1, selecting desired style and size before grinding.

STEP 3: **BREW ESPRESSO**

RECIPE INSPIRATION




On a solid level surface with funnel still attached, press tamper all the






Align portafilter with orange dot on group head.

5.



Place a large cup (400ml or greater) under the portafilter.


7.



When finished, the machine will beep again to signify the brew is complete. Carefully remove portafilter from group head. Dispose of grounds by tapping the surface of the basket over a container or knock box*.




Remove funnel from portafilter.



Fasten portafilter to align with lock arrow.

6.



Press START BREW. The machine will beep to signal the brew has started. The progress bar will illuminate, indicating the status of the brew. This will take about 30 seconds.









We know preferences vary for amount of milk desired in your cup, you can adjust the quantity of milk in the milk jug depending on your preference.


STEP 4: FROTH DAIRY OR PLANT-BASED MILK

1.




Fill the milk jug with your desired amount of milk.

3.




Match to whatever milk you are using (dairy or plant-based).

5.




This will take about 90 seconds.

7.



Push wand down using the rubber tab..
Machine will automatically purge to clean inside of wand after each use.

2.




Pull steam want out. Insert steam wand into milk jug, then push into milk jug platform.

4.



Use froth dial to pick froth thickness.


6.



Once frothing is complete, remove jug and immediately wipe steam wand with a damp cloth.

PLEASE USE CAUTION AS STEAM WAND WILL BE HOT

8.



Before pouring milk, tap the jug on a flat surface and swirl around to remove large bubbles. Pour frothed milk over espresso and enjoy.

UNDERSTANDING

BARISTA ASSIST TECHNOLOGY

You may notice your recommended grind setting change. This is Barista Assist Technology adjusting the recommended grind setting to help you get proper espresso extraction. When adding more beans, it may take 2-3 brews to reach the optimal grind setting. Over time, you may notice your recommended grind setting change to account for aging beans. This is normal. Ensure your current grind size always the recommended grind size for proper espresso extraction.

An accurate dose of coffee is also important for proper espresso extraction. Barista Assist Technology features a built-in scale that will grind until you have the proper dose of coffee grounds in your portafilter. Once the portafilter is installed in the grinding cradle, immediately let go to allow it to properly weigh and dose the coffee grounds.



THIS IS WHAT PROPER ESPRESSO EXTRACTION LOOKS LIKE

- Espresso will pour out at a slow, consistent rate.
- You will see a caramel-coloured liquid pouring out. That is your crema.
- There will be a layer of crema on the top of your drink. Feel free to tilt your cup to see if the layer of crema is still completely visible. If you can still only see that caramel colour, you have a properly extracted espresso shot.

Note that grind recommendation will only adjust over time for espresso brews. For filter coffee brews, grind recommendations will stay the same.

TIPS & TRICKS

BEST BEAN PRACTICES

For best results, use freshly roasted coffee beans.

When purchasing coffee beans, it's best to buy a bag with a "Roasted On" date rather than a "Best Before" date to ensure quality and freshness.

We recommend you use any coffee beans within 20 days of the "Roasted On" date.

ADJUSTING YOUR BREW STRENGTH AND TEMPERATURE

BREW STRENGTH ADJUSTMENT

Adjusting Brew Strength:

To adjust brew strength, press the STRENGTH button.

Espresso Strength Options:

- Taller, less concentrated: 4:1 water to grounds ratio
- • Default: 2.5:1 water to grounds ratio
- • Shorter, more concentrated: 2:1 water to grounds ratio

Coffee Strength Options:

- Mild: Less grounds will be dosed
- Default
- • Bold: More grounds will be dosed

CHOOSING THE RIGHT CUP

Ensure the cup you are using is appropriate for the size of your drink. For a hotter drink, use a cup that is a similar size to your drink.

The thickness of the material your cup is made of will also affect the temperature of your drink. For a hotter drink, use a cup made of thinner material.

PREHEATING BEFORE YOU BREW

Running hot water through the group head and portafilter will help preheat them and the machine for future brews.

To further increase the temperature of your drink, run a water-only double shot of espresso through the portafilter into the cup you would like to have your drink in. The temperature of your cup will impact the temperature of your drink. Discard the water, then dry the cup and portafilter. Then, proceed to brewing. See Water Flush for instructions.

BREW TEMP ADJUSTMENT

- 1 Hold the SIZE button for 3 seconds.
- 2 Rotate the centre dial to _h06, then press the centre dial to select.
- **3** Rotate the centre dial to select your desired setting, then press the centre dial to select.

LO: Low temperature

M: Medium temperature

HI: High temperature

To leave the additional settings menu, press the SIZE button.

The temperature setting will affect the extraction of espresso and the flavour of your drink. For best results and proper extraction, we recommend a low or medium temperature for darker roasts, and a medium or high temperature for lighter roasts.

MILK TEMPERATURE ADJUSTMENT

Adjust milk temperature in the additional settings.

- 1 Hold the SIZE button for 3 seconds.
- 2 Rotate the centre dial to _h07, then press the centre dial to select.
- **3** Rotate the centre dial to select your desired setting, then press the centre dial to select.

Low: Select this setting if your froth is coming out too hot or if you would like your froth to be slightly thinner.

Medium: Our barista-recommended default setting.

High: Select this setting if your froth is coming out too cold or if you would like your froth slightly thicker.

To leave the additional settings menu, press the SIZE button.

CLEANING & MAINTENANCE

DAY TO DAY MAINTENANCE

CLEANING THE BASKETS AND PORTAFILTER

Remember to clean these after each brew. Remove the basket from the portafilter and hand-wash both thoroughly.

EMPTYING DRIP TRAY



When the orange empty indicator rises enough to be visible, it's time to empty the main drip tray.

CLEANING THE FROTHER

Wipe with damp cloth: Do this immediately after frothing to prevent any milk from getting stuck to the steam wand.

Auto purge: After every froth, push the steam wand back into the down position without the jug installed to initiate an auto purge. This will help clean the inside of the steam wand after frothing. You can purge any time by pressing the PURGE button.

Removable whisk: Remove the whisk from the milk jug and handwash thoroughly after each use.

For a deeper clean of the whisk and steam wand, fill milk jug with water and a drop of dish soap and run the THIN froth program.

DISHWASHER-SAFE PARTS

- Funnel
- Whisk
- Cleaning disc
- Water reservoir
- Bean hopper
- All drip tray components.

PERIODIC MAINTENANCE

Below is how to run a descale and cleaning cycle. These are separate procedures and should be done whenever the corresponding light is illuminated.

DESCALE

Time to complete: Approx. 90 mins

Make sure to descale whenever the orange descale light turns on. Descaling removes any limescale and calcium build-up. Running the descale process will help ensure your system's peak performance.

- 1 Empty the drip tray.
- 2 Place an 535ml container under the group head, and place milk jug on the milk jug platform.
- **3 Recommended:** Using the provided Ninja Descale Solution, follow the directions on the package and fill the water reservoir up to but not exceeding the Max Fill.

OR Fill the water reservoir with 475ml white wine vinegar, then fill the rest of the reservoir with water to the "descale" line.

CLEANING CYCLE

Time to complete: Approx. 6 mins

Run a clean cycle whenever the "Clean" light is illuminated to flush out any residual oils and grounds inside the group head and shower screen. Cleaning out residual oils and grounds periodically will ensure the best brew quality.

- 1 Empty the drip tray so there is adequate room for the water output generated from the cleaning cycle. Not emptying the drip tray may cause overflow.
- 2 Fill the water reservoir up to but not exceeding the Max Fill line.
- **3** Insert the double basket in the portafilter.
- 4 Place cleaning disc on top of double basket, with the handle facing up. Place 1 cleaning tablet in the centre of the cleaning disc.





- 5 Install the portafilter into the group head. Ensure there is a cup below the portafilter.
- **6** Press the "Clean" button, then press the centre dial to start the cleaning cycle.

- 7 The machine will now start the process of backflushing the shower screen and group head and depositing the water and any build-up or sediment into the drip tray.
- 8 The cleaning cycle will take approximately 6 minutes to complete. The machine will beep when the clean cycle is completed.
- 9 After the clean cycle is completed, remove both the portafilter and drip tray with caution as there may be water in both. Hand-wash with warm water.
- 10 Check your cleaning disc to see if the tablet has fully dissolved. If it hasn't fully dissolved, repeat steps 1-10 (excluding step 4).

15

4

CLEANING & MAINTENANCE

PERIODIC MAINTENANCE

The following are instructions for the descale and cleaning cycles. These are separate procedures and should be done whenever the corresponding light is illuminated on the control panel.

DESCALING

Time to complete: approximately 90 minutes


When the descale light illuminates, you must run a descale cycle. If a descale isn't performed after the light turns on, drink quality will diminish and your machine may clog and stop working.

Descaling breaks down and removes limescale and mineral buildup inside the machine. Doing this will help maintain peak performance if routinely performed with a descale solution whenever the DESCALE light turns on.

1 Ensure the main drip tray is completely emptied, as some of the water brewed from the descale cycle will be deposited into the drip tray. Not emptying the main drip tray may cause overflow.



2 Dissolve the provided Ninja descale powder in a separate container with 1L of water. Pour solution mixture into water reservoir.



OR

Fill the water reservoir with 475ml of white vinegar, then fill the reservoir to the Descale line with water.

- 3 Insert the double basket into the portafilter.
- 4 Fasten the portafilter into the group head.
- **5** Ensure milk jug is placed on the milk jug platform with the steam wand inside.
- **6** Place an empty cup (at least 530ml) under the portafilter. You may have to remove the centre drip tray.
- **7** Press the DESCALE button, then press the centre dial to start the descale cycle.
- 8 The machine will start the descale cycle. The machine will flush solution through the steam wand and portafilter for approximately 90 minutes. The machine will count down the remaining time on the control panel.
- **9** The machine will beep indicating when the descale cycle is complete.
- **10** After the cycle is complete, remove the portafilter, main drip tray, and milk jug with caution, as there will be water in each.
- 11 Empty the contents of each and hand-wash with warm, soapy water to remove any solution that could affect the flavour of your coffee.
- 12 Fill the reservoir with fresh water up to, but not exceeding, the Max Fill line.
- 13 Install the main drip tray back on the machine and install the portafilter in the group head. Do not install the milk jug.
- 14 Flush the group head by running a M+ size classic brew.
- **15** Then, with the milk jug uninstalled, flush the steam wand by pressing the PURGE button.

RUNNING A CLEAN CYCLE

Time to complete: approximately 6 minutes

A clean cycle flushes out residual oils or grounds that are built up in and around the group head. The CLEAN light will automatically illuminate to indicate when a clean cycle is required. You may also run a clean cycle if you notice a change in brew quality. The clean cycle requires the cleaning disc (included with the machine and storable in the accessory storage) and a cleaning tablet (also included and available for purchase on ninjakitchen.com/accessories).

Follow these steps to run a clean cycle:

1 Ensure the main drip tray is completely empty as the water brewed from the clean cycle will be deposited into the main drip tray. Not emptying the main drip tray may cause overflow.



- 2 Fill the water reservoir up to but not exceeding the Max Fill line.
- 3 Insert the double basket in the portafilter.
- 4 Place the cleaning disc on top of the double basket, with the handle facing up.



5 Place 1 cleaning tablet in the centre of the cleaning disc.



- 6 Fasten the portafilter in the group head.
- **7** Press the CLEAN button, then press the centre dial to start the clean cycle.
- **8** The machine will start the process of backflushing the shower screen and group head and depositing the water and sediment from the clean cycle into the main drip tray.
- **9** The clean cycle will take approximately 6 minutes to complete. The machine will beep when the clean cycle is complete.
- 10 After the clean cycle is complete, remove both the portafilter and main drip tray with caution, as there may be water in both. Handwash with warm soapy water.

NOTES

1



For accessories and replacement parts, visit ninjakitchen.co.uk/ninja-parts-accessories