

## STRAW ASSEMBLY



**1.**  
Align and secure  
straw onto  
silicone boot



**2.**  
With the cap  
open, insert the  
straw through the  
bottom of the lid



**3.**  
Twist the lid  
onto the vessel  
keeping the  
cap open



**4.**  
Close the cap of the  
lid once secured on  
the cup and enjoy!

Find your perfect colour  
at [ninjakitchen.co.uk](http://ninjakitchen.co.uk)



Watermelon Bubblegum



Blue Raspberry

\*Colours may vary by retailer



@ninjakitchen.co.uk

© 2025 SharkNinja Operating LLC.

AUTO-iQ and NINJA are registered trademarks in the  
United Kingdom of SharkNinja Operating LLC.

DB351UKSeries\_QSG\_MP\_Mv10\_251121

# NINJA Blend BOSS

TUMBLER BLENDER WITH  
LID AND STRAW

## QUICK START GUIDE

**AUTO-iQ** uses timed blending and  
pauses for the perfect output.

For best results, allow programs  
to run until complete.



### Blend

Best for lighter protein shakes  
and fresh fruit/vegetable juices  
RUN TIME: 60 SECONDS




### Smoothie

Best for smoothies with  
frozen fruit, vegetables, ice,  
and leafy greens  
RUN TIME: 55 SECONDS



### Ice Crush

Best for frozen drinks  
and cocktails  
RUN TIME: 50 SECONDS



### PROGRESS BAR

Lights illuminate  
as program runs.

Lights shut off  
automatically when  
program is complete.



For helpful tips and tricks  
on how to use your Ninja  
Blendboss scan the QR code.

## ASSEMBLY



**1.** Fill cup with desired contents, referencing the **MAX FILL** line. When adding liquid, reference **MIN FILL** line. Screw on the blade assembly until you have a tight seal.



**2.** Flip cup upside down and align the dot on the blade holder to the dot on the motor base. Rotate cup clockwise until it clicks into place.



**3.** Select any program to begin blending immediately.



**4.** When blending is complete, remove the cup from base. Then, remove the blade assembly from cup.

**NOTE:** When making thicker recipes like smoothies or protein shakes, pull the sleeve back to make sure all ingredients are fully blended before taking on the go.



### 5. Take it to go!

Place the lid on the travel tumbler, and turn clockwise to seal. If using the straw, follow assembly and installation instructions. Lid is designed to not leak, drip or spill when locked.



#### NOTE:

- The lid threads on for both left- and right-handed use. Hold the cup in your preferred hand, face the lid toward you, and twist clockwise to secure.
- **DO NOT** microwave, freeze, or place hot beverages in the travel tumbler.

## CUP CLEANING

### Stuck-on ingredients in the travel tumbler?

1. Rinse the cup and blade assembly under **WARM WATER** after processing.
2. Fill the cup halfway with warm water and add **1-2 SMALL DROPS** of dish soap.
3. Screw on the blade assembly and press **BLEND**.
4. Once complete, empty contents and rinse under warm water.



#### Dishwasher

Cup, straw, CrushBlade™ assembly, and lid in the **open position** are all top-rack dishwasher safe.



#### Hand-Washing

Wash cup, lid, straw, and CrushBlade Assembly in warm, soapy water. Clean CrushBlade Assembly within one hour of use for best results. When cleaning use a soft bristle brush or non-abrasive sponge. Gently scrub all surfaces, including crevices, slots, and interlock where buildup may occur.



**WARNING:** Handle the CrushBlade Assembly with care when washing, as the blades are sharp. Contact with the blades' edges can result in laceration.

For questions or to register your product, visit us online at [ninjakitchen.co.uk](http://ninjakitchen.co.uk)

