Please be sure to read the enclosed Ninja® Information Booklet prior to using your unit.

 $(\mathbf{ })$



PRO COMPLETE QUICK ASSEMBLY

NUTRI NINJA[®] CUPS



()

1. Screw on the blade assembly clockwise until you have a tight seal.



Turn the cup upside down and lower it onto the base.

2.



3. Turn the cup clockwise to lock into place.

CLEANING

All plastic jars, lids, and blades are dishwasher safe. Place lids and blades on the TOP RACK only.

NOTE: The Double Wall Stainless Steel Nutri Ninja® Cup is NOT dishwasher safe. To clean, carefully hand wash in warm, soapy water with a soft cloth.

WARNING: Handle the blade assemblies with care when washing, as the blades are sharp. Contact with the blades' edges can result in laceration.

QUESTIONS? We're here to help. Call 0800 862 0453 or visit www.ninjakitchen.eu

۲

Please be sure to read the enclosed Ninja® Information Booklet prior to using your unit.

 $(\mathbf{ })$

NUTRI NINJA Auto-iQ

ONE-TOUCH INTELLIGE

QUICK TIPS

Thanks to smart settings with unique variable blending patterns, you can expect smooth, consistent, professional-quality results every time—no guesswork required.



()

AUTO-iQ[®] SMOOTH BOOST[™]

The Auto-iQ Smooth Boost button controls the level of smoothness for all types of drinks.

SMOOTH BOOST EXTRACT

For our finest breakdown of fruits and veggies, ensure **SMOOTH BOOST "YES"** is selected, then press **Auto-iQ EXTRACT.**

SMOOTH BOOST BLEND

To whip up ultra-creamy smoothies and frozen drinks ensure **SMOOTH BOOST "YES"** is selected, then press **Auto-iQ BLEND.**

TIP

If you'd like your drink to have more texture and fullness, press **SMOOTH BOOST "NO"**.



• **Great for**: Leafy greens, fibrous fruits and vegetables, seeds and ice.



• **Great for:** Milkshakes, frozen drinks, smoothies and sauces.

QUESTIONS? We're here to help. Call 0800 862 0453 or visit www.ninjakitchen.eu