

IMPORTANT SAFETY, USE & CARE INFORMATION

Thank you for purchasing Ninja® Foodi™ ZeroStick® Bakeware and welcome to the Ninja family! We hope you love your bakeware and will be inspired to create something new in your kitchen.

BEFORE FIRST USE

Read all instructions carefully. Wash bakeware in hot, soapy water, then rinse and dry thoroughly.

IMPORTANT SAFETY GUIDELINES

- Keep small children away from the oven while baking.
- Some pets have extremely sensitive respiratory systems and should be kept away from the kitchen area.
- For oven use only. DO NOT use bakeware on the hob or over a direct flame.
- Use caution when handling hot bakeware and always have potholders available for use.
- Never use your bakeware in the microwave.

HEAT SETTINGS

It is not recommended to exceed a baking temperature of 260°C. This bakeware efficiently conducts heat - monitor your oven temperature and baking times for the first few uses and reduce as necessary.

DO NOT use your bakeware under the grill as temperatures often exceed 260°.

USE & CARE

Your bakeware is dishwasher safe, but hand washing with a mild washing up liquid is always best to keep it looking and performing like new.

- Follow recipe instructions, greasing and flouring as directed.
- Use of aerosol cooking sprays is not recommended. These burn at low temperatures and will leave a residue that leads to sticking.
- Avoid soaking overnight. Rinse and dry thoroughly after washing.
- Do not use oven cleaners or dishwasher detergent tablets to clean bakeware as they will damage the finish.
- Avoid cleaning with abrasive cleansers or scouring pads.
- Foods that contain a high oil content may stain your bakeware but will not affect performance.

STORAGE

Place a paper towel or soft cloth between bakeware to help protect the coating when stacking. Direct contact between pans during storage could lead to scratching or coating damage.

UTENSIL USE

Use only silicone, nylon or wooden utensils. DO NOT use sharp metal utensils such as knives or forks.

DO NOT cut directly on your bakeware as it will damage the coating and void the guarantee.

REGISTER YOUR PURCHASE

Register your Ninja® Foodi™ ZeroStick® Bakeware to stay up to date with what's new from Ninja and learn about your guarantee.

For additional info, tips, tricks, and FAQs, visit ninjakitchen.uk

SharkNinja Europe Limited,

3150 Century Way,

Thorpe Park,

Leeds, LS15 8ZB

ninjakitchen.uk

ZEROSTICK is a registered trademark of SharkNinja Operating LLC.

FOODI and NINJA are trademarks of SharkNinja Operating LLC.

© 2022 SharkNinja Operating LLC.

PRINTED IN CHINA