

50QT / 47L COOLER

50QT/47L COOLER

GET TO KNOW Your cooler

STURDY HANDLES Easy-to-carry design.

THICK INSULATION

Inner-wall insulation delivers longer-lasting ice retention.

LOCKABLE LID & DRAWER

Easy-close, one-handed latch seals lid securely.

DRAIN PLUG

Mess-free, easy drainage.

NINJA FROST**VAULT** DRY ZONE

Easy access to your essentials, keeping them cold, dry, and separate from the main cooler full of ice.












ENGLISH

- A S Y

Ninja Frost**Vault** Technology delivers food-safe fridge temps under 4.5°C. Keeps your food cold, dry, and separate from the main cooler full of ice vs. some other coolers with wire baskets that can quickly reach unsafe food temps (over 16°C).

Ice retention and fridge safe temperatures are assessed by measuring the time (in days) for ice to reach 4.5°C and begin melting. Testing is conducted in controlled lab conditions; actual performance may vary based on external factors and real-world usage.





GET THE MOST OUT Of your ninja Frost**vault** zone

PRE-CHILL

For best results, load the drawer with pre-chilled items.

FILL IT UP

Lay ice on the bottom of the main cooler to keep drawer contents cold. **DO NOT** add ice to the drawer. Fill the drawer completely with food or drinks. **DO NOT** overfill.

KEEP CLOSED

Keep the drawer closed when not in use, and limit opening and closing to maintain optimal temperature.



MAXIMISE ICE RETENTION

THE RIGHT RATIOS

For the best Frost**Vault** experience, we recommend filling your cooler's main compartment with 33 cans and a minimum of 11kg of ice. **DO NOT** use dry ice. Ice does not need to be placed in the drawer.

PRE-CHILL THE COOLER

Before using, leave the cooler open in a cool space for a few hours or overnight. For even better results, fill with ice to lower the inside temperature. Drain when ready to use, then add fresh ice and pre-chilled contents.

PACK EFFICIENTLY & KEEP CLOSED

Fill the cooler completely with ice, food, and drinks, then use a towel to fill empty space if necessary. To retain cold temperatures and ice, keep the cooler closed. Keep shaded or cover with a tarp or blanket for best results.

COOLER STORAGE AND PLACEMENT

Ensure your cooler is on an even, level surface. **DO NOT** stand on the cooler.

After use, leave the lid and drawer open until the cooler is completely dry to prevent mold or odors. Close the lid and drawer then store the cooler in a cool, dark, and dry place.

OR

NINJA

SECURE Your cooler

Weave one tie-down strap through each handle.

> Wrap two straps, one around each handle.

CLEANING YOUR COOLER

FIRST CLEANING

Before first use, clean the cooler with warm, soapy water. Rinse thoroughly and let air-dry.

ROUTINE CLEANING

After each use, rinse your cooler with warm, soapy water. Scrub the interior with a soft brush or cloth to remove any residue or odors. Rinse thoroughly and let air-dry.

DEEP CLEANING

Apply a paste of baking soda and water to stubborn stains or odors and scrub gently. Rinse thoroughly and let air-dry.



DRAWER CLEANING

Pull Ninja FrostVault Dry Zone drawer out completely, lift at an angle, and remove like you would a dresser drawer. Rinse or wipe away any sand or dirt between uses. Clean with warm, soapy water. Rinse thoroughly and let air-dry. To reinsert, put back in at an angle and close.

Remember, always ensure your cooler is completely dry before closing and storing to prevent mold and mildew growth.

Ninja

PRODUCT REGISTRATION - FROSTVAULT

If you as a consumer purchase a product in the United Kingdom, you automatically receive guarantee rights regarding the product quality (your "legal rights"). You can exercise these legal rights against your retailer. However, at Ninja we have such confidence in the quality of our products (the "Products") that we offer you an additional manufacturer's guarantee of five years (2 by default and 3 upon registration). This guarantee only applies if the product is purchased new and unused. These terms and conditions apply only to our guarantee – this does not affect your statutory rights as a buyer. The following terms describe the terms and scope of our guarantees provided by SharkMinja Europe Ltd, Ist/Znd Floor Building 3150, Thorpe Park, Century Way, Leeds, England, LSI5 8ZB ("us", "our", "we"). They do not affect any statutory rights arising from the purchase agreement with the retailer from whom you purchased the product or your retailer's obligations arising from the purchase and those of your sales contract with them. This also applies if you purchased the product directly from Ninja.

Ninja-guarantee

Your new product should work as long as possible. The guarantee plays an important role in this and reflects how much confidence the manufacturer has in his product and the manufacturing quality. Our customer service helpline (+44 (0)800 862 0453) is available from Monday to Friday from 9.00 am to 6.00 pm. The call is free, and you will immediately be put through to a Ninja employee. You can also get online support at **www.ninjakitchen.co.uk**.

How do I register my guarantee?

You can register your guarantee online within 28 days from the date of purchase. To save time, please have the following information about your device ready:

- Model
- Serial number (if available)
- Date of purchase of the product (proof of purchase or delivery) To register, please visit **www.ninjakitchen.co.uk**.

IMPORTANT

• Your product is guaranteed for five (5) years from the date of purchase. (2 years by default plus 3 years upon registration).

 Please keep proof of purchase at all times. If a guarantee claim occurs, we need the proof of purchase to verify that the information you have given us is correct. If you are unable to provide a valid proof of purchase, you will lose your guarantee claim.

What are the benefits of registering my guarantee?

When you register your guarantee, you can also subscribe to our newsletter with tips, advice and competitions. Through the newsletter you will receive the latest news about new technologies and products from Ninja. When you register your guarantee online, you will immediately receive confirmation that we have received your data. Details of our privacy policy can be found at www.ninjakitchen.co.uk.

How long is the guarantee on our products?

Because we place great trust in our design and quality control, your guarantee for your product is valid for five (5) years. (2 years by default plus 3 years upon registration).

What does the guarantee cover?

Replacement of your product (at Ninja's option), including all parts and labor in the event of instructions, materials and workmanship defects (including transportation and shipping costs). Our guarantee is in addition to your rights as a consumer.

What is not covered by the guarantees?

- Normal wear and tear.
- Accidental damage, errors caused by negligent use or care, incorrect operation, neglect, careless or improper handling of the product that is not done in accordance with the instructions in the supplied user manual from Ninja.
- Use of the product for purposes other than normal household use.

What happens when my guarantee expires?

Ninja does not make devices that only work for a limited time. We appreciate it when customers want to have their kitchen appliance repaired even after the guarantee period has expired. In this case, please contact our customer service helpline on +44 (0)800 862 0453 and ask about our customer program for expired guarantees.



Upon registration with Ninja. When used as directed in the quick start guide.

© 2024 SharkNinja Operating LLC. NINJA FROSTVAULT is a pending trademark application in the United Kingdom and in theEuropean Union of SharkNinja Operating LLC. SharkNinja Germany GmbH, Rotfeder-Ring 9, 60327 Frankfurt am Main, Germany SharkNinja Europe Ltd, 1st/2nd Floor Building 3150, Thorpe Park, Century Way, Leeds, England, LSTS 82B FB151EU_QSG_MP_Z1_240927_Mv1_UK