Please make sure to read the enclosed safety instructions prior to using your unit.



Quick start guide & get started recipes



NOTE: Unit colour, number of Deluxe Lids and programs may vary by model.



SCAN & WATCH HOW IT WORKS www.ninjakitchen.co.uk

Assembly & Processing

Disassembly & Cleaning



1. Plug in unit first Unit will not run if outer bowl is installed before unit is plugged in.

NOT



2. Install Creami Deluxe Tub Remove lid from tub and check that ingredients have not been frozen at an angle. Place tub with frozen base in outer bowl.



Install Creamerizer Paddle Press and hold paddle latch on top of outer bowl lid, then insert paddle in bottom of lid. Release latch to secure paddle.



bowl handle so lines on lid and handle align. Rotate lid clockwise to lock.

If control panel will not illuminate, ensure unit is properly assembled. See troubleshooting section of the safety instructions if install light is illuminated.



Install outer bowl

After plugging in unit, place outer bowl on base with handle centred on unit. Twist handle to the right to raise platform and lock bowl in place (signalled by a click).



6. Select processing mode & program

Press Power. Press a processing mode (TOP. FULL. or BOTTOM). then turn dial to select a program and press dial to begin processing.

Remove bowl When program is complete, hold release button on left of motor base and twist bowl handle clockwise, then pull away from unit to remove.

7.

Bowl Release Button

To remove outer bowl, hold

release button.

To process the whole tub, press FULL. To process just the top half, press TOP. To process the remaining half of the tub, press BOTTOM. TOP and BOTTOM processing zones are only available with SCOOPABLE programs.



Remove lid Press the lid unlock button and twist to remove lid.



Use a spoon to create a 4cm wide hole that reaches the bottom of the processed ingredients. Add chopped or broken mix-ins to the hole. Select the same processing mode. then select MIX-IN



9 If not adding mix-ins, RE-SPIN can be used on a crumbly or powdery output to make it creamy. RE-SPIN is often needed for very cold bases. Do not RE-SPIN before using MIX-IN program. Select the mode prior to selecting RE-SPIN.



Remove Deluxe Tub & paddle

Lift tub out of outer bowl. Rinse outer bowl lid to remove any sticky residue or pieces wedged in the paddle. Remove paddle by pressing paddle latch on top of lid. All parts are top-rack dishwasher safe and can also be hand-washed.

Start Here! Prep Your Deluxe Raspberry & Orange Slushi Recipe*



Raspberry & Orange Slushi

PREP: 5 minutes | **FREEZE:** 24 hours | **PROGRAM TIME:** 5 minutes | **MAKES:** 3 servings

INGREDIENTS

For Freezing 60g granulated sugar

250g fresh raspberries 230ml hot orange juice

DIRECTIONS

Place the sugar and

CREAMi Deluxe Tub.

fork until paste like.



FREEZE for 24 hours

Once cooled, place raspberries into an empty storage lid on tub and freeze for 24 hours. Combine mixture with a

Add hot orange juice to the DRINKABLE FREEZE FILL line and stir until sugar has dissolved.

If your pour-in contains alcohol, select FROZEN DRINK.



For Processing



PROCESSING MODE FULL SLUSHI

personalised ice cream recipe.

10 minutes before Press FULL, then use the processing remove tub dial to select SLUSHI and from freezer and remove press dial to begin processing. Add 4 additional tablespoons of

Add pour-in to the DRINKABLE POUR-IN FILL line. Please use the Quick Start Guide for assembly and processing information.

lid from tub.

vour desired pour-in. then select RE-SPIN. Once processing is complete, transfer slushi

to a glass and serve immediately.

PREFER MORE SIPPABLE? If you prefer a thinner frozen drink after processing, simply add 2-4 additional tablespoons of your desired pour-in, then select RE-SPIN.

For Processing

Pour-in: water, alcohol, or juice

Perfectly Personalised Ice Cream

PREP: 5-10 minutes | FREEZE: 24 hours | PROGRAM TIME: 2 minutes | MAKES: 6 servings

INGREDIENTS

27g cream cheese, softened

80g caster sugar

Flavouring, 1¹/₂ teaspoons extract of your choice OR 3 tablespoons of cocoa powder

PICK YOUR FLAVOUR









45g mix-ins of your choice (optional)



Fruit extract

Cocoa powder

Vanilla extract

Mint extract

Almond extract

MAKE IT DAIRY-FREE Use vegan cream cheese for cream cheese, <u>unsweetened</u> coconut cream for double cream and **unsweetened** oat milk for milk. Whisk the coconut cream until smooth, then add the remaining ingredients.



Microwave cream cheese for 10 seconds.

Add sugar and flavour. then whisk the mixture until it looks like frosting.



Slowly mix in the double cream and milk until fully combined and sugar is dissolved.



225ml double cream

345ml whole milk

Pour base into CREAMi Deluxe Tub. Place storage lid on Deluxe Tub and freeze for 24 hours.



Remove tub from freezer and remove lid from tub

Refer to previous page for Assembly & Processing instructions. Select processing mode (FULL, TOP, or BOTTOM), then select ICE CREAM.

PICK YOUR MIX-INS TO ADD A PERSONAL TOUCH

Prepare 45g of mix-ins, which can include your favourite crushed sweets, frozen fruits, chopped nuts, chocolate pieces, and more.



With a spoon, create a 4cm wide hole that reaches the bottom of the processed ingredients.

Add mix-ins to the hole. Select the mode previously processed, then select the MIX-IN program.



Make two flavors from one base. See page 7 of Inspiration Guide to get started.

REGISTER ONLINE!

Register your product at ninjakitchen.co.uk

Or CALL US FREE ON: 0800 862 0453



Scan the code for online help, FAQs, and How-To Videos. ninjakitchen.co.uk



©2023 SharkNinja Operating LLC. All rights reserved. Made in China. NINJA is a registered trademark in the United Kingdom of SharkNinja Operating LLC.

NC501UK_QSG_MP_231012_Mv1